

May 12, 1997

## ADDENDUM 1

In October 1995 an order was placed by the City of Tampa for a ChemScan Process Analyzer System.

This system is currently installed and operating at the Howard F. Curren Wastewater Treatment Facility (formerly known as Hookers Point). The delivered system differs from the demonstration system in the following manner:

- a. The delivered system has a six sample line manifold and a series of manual valves which permit a choice of sample points for the "old" and "new" nitrification tank effluents, the "old" and "new" denitrification filter banks and the final plant effluent.
- b. Nitrite has been dropped as a parameter for the delivered system.
- c. Ammonia has been added as a parameter for certain sample points. The delivered system includes an ammonia sample conditioning unit.
- d. Automatic zeroing and cleaning is available on the delivered system.