

ChemScan® mini Fe

IRON ANALYZER

Real-time Data for Process Monitoring, Cost Control

The new single parameter in-line analyzer family from ASA Analytics utilizes years of ChemScan® experience and proven technology to provide reliable and accurate analysis of water and waste water. This device has been designed from the ground up to reduce maintenance requirements, includes large ID sample tubing to minimize plugging and only needs quarterly reagent refills.

FEATURES

- Automatic Analysis Utilizing 5-Sulfosalicylic Acid Method
- Low Maintenance
- Proven Sample Handling with Large I.D. Flow Paths
- Simple Field Adjustable Calibration
- Sample Blank to Eliminate Background Interference
- Automatic Cleaning

CAPABILITIES

- Automatic Analysis
- Continuous Output
- Multiple Data Communication Interface Options

APPLICATIONS

- Potable Water
- Wastewater Effluent

BENEFITS

- High Reliability
- Low Capital Cost
- High Accuracy
- Low Operating Cost

SPECIFICATIONS

| | |
|----------------------|---|
| Range: | 0.01 - 5.0 mg/L (Method 1039) 0.02 - 20.0 mg/L (Method 1037) |
| Accuracy: | 2% of value or 2x detection limit (whichever greater) |
| Cycle Interval: | 8 minutes to 9999 minutes (field programmable) |
| Environment: | 5 - 50 degrees C (method dependent) |
| Power: | 100 - 240 VAC, 50 W |
| Enclosure: | NEMA 4X |
| Safety Approval: | CSA-US |
| Sample Requirements: | 0.5 - 1 Liter/analysis, pressure 2 to 10 psi, <150 mg/L TSS, <60 NTU |
| Maintenance: | Reagent replacement every 3 months, pump kit yearly |
| Relay Contacts: | 1 SPDT Concentration, 1 SPDT Programmable |
| Serial Interface: | RS-232 Maintenance Port |
| Analog Output: | Isolated 4-20 mA |



asa
ANALYTICS

"Monitoring a World of Water"

Applied Spectrometry Associates, Inc.
2325 Parklawn Drive, Suite I, Waukesha, WI 53186
262-717-9500, Fax 262-717-9530

Published 4/4/18

www.asaAnalytics.com